


Motorized Recreational Vehicle

Extended Protection



Travel with peace of mind.

Nationwide Protection

FCPP covers breakdowns occurring anywhere in Canada and the continental United States.

Transferable Coverage

In the event you choose to sell your recreational vehicle, you can apply to transfer the coverage to the next owner for the remainder of the contract/policy term.

Reducing Deductible

Your deductible will be reduced by \$50 when repairs are performed at the original selling dealer.

Extended Eligibility

Motorized recreation vehicles that are still under manufacturer's warranty are still eligible for New RV coverage.



Travel with peace of mind.

Travel with a First Canadian Protection Plan.

Today's recreational vehicles are equipped with all the comforts of home. The multitude of amenities and features suit every lifestyle and cater to all your travel needs.


But are you worried about unexpected breakdowns and unforeseen costly repairs? With the cost of service and components increasing each year, an expensive repair could ruin your travel plans. **Leave your worries behind with FCPP.**

- FCPP will quickly and efficiently handle your claim to ensure your vacation is not delayed or cut short. **Repair costs are paid directly to the repair facility on authorized services**, saving you from out-of-pocket expenses and the inconvenience of waiting for reimbursement.
- Choose a protection plan to guard you against these unplanned expenses.

It's better to have protection and NOT NEED it, than to NEED it and NOT HAVE ANY.



Select the right plan for You.



1	Engine	●	●	●	●
2	Transmission	●	●	●	●
3	Drive Axle	●	●	●	●
4	Steering		●	●	●
5	Brakes		●	●	●
6	Electrical		●	●	●
7	Air Conditioner		●	●	●
8	Fuel System		●	●	●
9	Suspension		●	●	●
10	Heating/Cooling System		●	●	●
11	Heating System Assembly			●	●
12	Converter/Battery Charger			●	●
13	Water Heater Assembly			●	●
14	Waste System Assembly			●	●
15	Fresh Water System Assembly			●	●
16	Air Conditioning / Ventilation Assembly			●	●
17	Range & Oven Assembly			●	●
18	LP Gas System Assembly			●	●
19	Diesel Fired Heating System Components			●	●
20	Refrigerator Assembly			●	●
21	Generator/Electrical Assemblies			●	●
22	Awnings			●	●
23	Stationary Leveling Jack System**			●	●
24	Power Step**			●	●
25	Slide Out(s)			●	●
26	Engine Retarder				●
27	Emissions				●
28	Deluxe Components**				●
29	Audio/Visual Package**				●

*Drive Coverage - available on new units only

**Factory installed or approved




First Canadian Protection Plans

TOLL FREE 1.800.381.2580

Schedule of Coverage - Motorized Recreational Vehicle Protection

ENGINE

Cylinder Block and all internally lubricated parts contained within the engine including:



Cylinder Head(s) Pistons; Piston Rings	●	●	●	●
Connecting Rods & Bearings; Crankshaft	●	●	●	●
Crankshaft Main Bearings; Camshaft	●	●	●	●
Camshaft Bearings; Cam Followers	●	●	●	●
Timing Chain; Timing Gears; Timing Chain Cover	●	●	●	●
Timing Chain Tensioners	●	●	●	●
Engine Serpentine Belt Tensioner	●	●	●	●
Idle Pulley; Idle Pulley Bearings	●	●	●	●
Flywheel (excluding teeth)	●	●	●	●
Rocker Arms; Rocker Shafts; Rocker Bearings	●	●	●	●
Cylinder Head Valves; Valve Seals; Valve Seats	●	●	●	●
Valve Lifters; Valve Springs; Valve Retainers	●	●	●	●
Push Rods; Water Pump; Oil Pump	●	●	●	●
Oil Pump Housing; Harmonic Balancer	●	●	●	●
Oil Pan (excluding drain plug threads)	●	●	●	●
Intake & Exhaust Manifold; Valve Covers	●	●	●	●
Engine Mounts	●	●	●	●
Diesel Fuel Injectors (except for wear and tear and/or contamination)	●	●	●	●
Diesel Fuel Injection Pump; Diesel Vacuum Pump	●	●	●	●
Turbocharger or Supercharger (original factory installed parts or components only)	●	●	●	●
Turbocharger or Supercharger Housing and the Internal Parts (when damage due to the failure of an internally lubricated part)	●	●	●	●
Seals & Gaskets**	●	●	●	●

TRANSMISSION

(Automatic) Transmission Case (only if damaged from within) and all Internal Parts contained within the Transmission Case:

Input Shaft; Torque Converter; Vacuum Modulator	●	●	●	●
Transmission Mounts; Oil Pan; Cooler; Seals & Gaskets**	●	●	●	●

DRIVE AXLE



Final Drive Housing; Drive Axle Case (only if damaged from within) and all internally lubricated parts contained within the Drive Axle Case	●	●	●	●
Differential Cover; Axle Shaft	●	●	●	●
Drive Shaft Universal Joint; Drive Shaft; Shaft; Hub Bearings	●	●	●	●
Tapered Wheel Bearings; Seals & Gaskets**	●	●	●	●

STEERING

Steering Box and all internal parts contained within	●	●	●	●
Rack & Pinion Gear; Power Steering Pump	●	●	●	●
Power Steering Hoses; Steering Spindle	●	●	●	●
Pitman Arm; Idler Arm; Centre Link	●	●	●	●
Upper Steering Column Shaft	●	●	●	●
Relays; Sensors; Seals & Gaskets**	●	●	●	●


BRAKES

Master Cylinder; Vacuum Assist Booster; Hydro Assist Booster	●	●	●	●
Disc Brake Caliper; Wheel Cylinders	●	●	●	●
Compensating Valve	●	●	●	●
Metal Brake Hydraulic Lines	●	●	●	●
Hydraulic Control Unit	●	●	●	●
Combination Valve Air Brakes; Compressor	●	●	●	●
Diaphragm; Treadle; Disc Caliper; Compensating Valve	●	●	●	●
Slack Adjusters; ABS System; Brake Pedal; Seals and Gaskets**	●	●	●	●

ELECTRICAL

Alternator; Digital Instrument Cluster	●	●	●	●
Instrument Panel Printed Circuit Board	●	●	●	●
Voltage Regulator; Starter Motor	●	●	●	●
Starter Solenoid; Starter Drive	●	●	●	●
(Factory) Engine Compartment Wiring Harness	●	●	●	●
Electronic Ignition Module	●	●	●	●

ELECTRICAL (CONT.)




Distributor Pick-up Coil	●	●	●	●
Ignition Switch; Ignition Lock Cylinder	●	●	●	●
Ignition Coils	●	●	●	●
Front & Rear Wiper Motor; Washer Pump & Switch	●	●	●	●
Manually Operated Electrical Switches	●	●	●	●
Electronic Ignition Module	●	●	●	●
Body Computer / Control Module	●	●	●	●
Powertrain Control Module; Stop Lamp Switch	●	●	●	●
Headlamp Switch; Turn Signal Switch	●	●	●	●
Heater/AC Control Assembly; Blower Motor Resistor	●	●	●	●
Horns; Factory Installed Cruise Control Module	●	●	●	●
Cruise Control Transducer	●	●	●	●
Cruise Control Servo & Amplifier	●	●	●	●
Cruise Control Engagement Switch	●	●	●	●
Power Vent Motors; Door Glass Power Window Motor	●	●	●	●
Power Window Switch	●	●	●	●
Power Seat Motor; Power Seat Switch	●	●	●	●
Power Mirror Motor; Power Mirror Motor Switch	●	●	●	●
Power Antenna Motor (excluding Mast)	●	●	●	●
Power Door Lock Actuator & Switch (includes baggage door)	●	●	●	●
Battery Paralleling Switch; Back-up Alarm; Safety Restraints	●	●	●	●

AIR CONDITIONING

Condenser; Compressor; Clutch Assembly & Pulley	●	●	●	●
Air Conditioning Lines & Hoses; Evaporator	●	●	●	●
High/Low Compressor Cut-off Switch; Circuit Breakers; Expansion Valve	●	●	●	●
Pressure Cycling Switch; Orifice Tube; Ducts and /Outlet Hoses; Temperature Programmer	●	●	●	●
Seals & Gaskets**	●	●	●	●

Schedule of Coverage - Motorized Recreational Vehicle Protection

FUEL SYSTEM



Fuel Pump; Fuel Tank	●	●	●
Mechanical Fuel Tank Sending Unit	●	●	●
Fuel Rail; Fuel Pressure Regulator	●	●	●
Metal Fuel Delivery Lines; Fuel Tank Selector Valve; Fuel Injection Pump; Fuel Injection Sensor	●	●	●
Diesel Fuel Injectors/Nozzles; Diesel and Gasoline Fuel Injectors	●	●	●

SUSPENSION

Upper & Lower Control Arms	●	●	●
Control Arm Shafts or Bushings	●	●	●
Upper & Lower Ball Joints	●	●	●
Torsion Bars & Mounts or Bushings	●	●	●
Stabilizer Bar (excluding any electronic disconnect system); Stabilizer Links & Bushings	●	●	●
King Pins; Steering Spindle; Spindle Support; Air Suspension	●	●	●

HEATING / COOLING SYSTEM

Heater Core; Front & Rear Blower Motor	●	●	●
Engine Cooling Fan & Motor; Hydraulic Fan Clutch Hub	●	●	●
Radiator; Hot Water Valve	●	●	●


HEATING SYSTEM ASSEMBLY

Furnace: Heat Exchanger; Squirrel Cage	●	●
Time Delay Relay; Igniter; Burner Assembly	●	●
Thermocouple; Gas Valve; Thermostat	●	●
Blower Motor; Switches; PC Board	●	●
Seals & Gaskets**	●	●

CONVERTER / BATTERY CHARGER

Cooling Fan Motor; Electric Relays	●	●
Circuit Boards	●	●

WATER HEATER ASSEMBLY



Burner Assembly; Tank; Thermostat; Thermocouple	●	●
Thermal Fuse; Gas Valve; Electronic Ignition Assembly	●	●
PC Board; Switches; Heating Elements; Bypass Valves	●	●
Pressure Relief Valve; Wiring Harness	●	●
Seals & Gaskets**	●	●

WASTE SYSTEM ASSEMBLY

Toilet; Vacuum Breaker; Float Assembly	●	●
Ball Valve; Slide Valve; Water Inlet Valve; Sink(s)	●	●
Holding Tanks; Gate Valves & Connections	●	●
Seals & Gaskets**	●	●

FRESH WATER SYSTEM ASSEMBLY

Water Pump; Compressor; Water Tank; Water Lines	●	●
Traps; Fitting & Faucets; Seals & Gaskets**	●	●


AIR CONDITIONING / VENTILATION ASSEMBLY

Compressor; Condenser; Evaporator; Accumulator; Heat Pump	●	●
Expansion Valve; Thermostat; Receiver/Dryer	●	●
Blower Motor; High-Low Cut Off Switches	●	●
Pressure Cycling Switches; Relays; Heat Strip	●	●
Fans; PC Board; Seals & Gaskets**	●	●

RANGE & OVEN ASSEMBLY

Burner Assembly; Thermostat; Thermocouple	●	●
Burner Valves; Ignition Assembly; Power Hood	●	●
PC Board; Microwave Oven; Serviceable Seals & Gaskets**	●	●

LP GAS SYSTEM ASSEMBLY



Regulators; Gas Bottles; Gas Bottle Valve	●	●
Mounting Brackets; Pigtails	●	●
LP Gauges; LP Gas Lines & Fittings	●	●

DIESEL FIRED HEATING SYSTEM COMPONENTS

(Maximum aggregate claim amount of \$5,000 over the Plan Term, including taxes)

Heating Elements: Circulating Pumps; Relays	●	●
Burner Assembly; Circuit Boards; Seals & Gaskets**	●	●

REFRIGERATOR ASSEMBLY

Thermostat; Thermocouple; Cooling Unit	●	●
Burner Assembly; Igniter; Fans; PC Board	●	●
Serviceable Refrigerator Door Seal; Wiring Harness	●	●
Refrigerant; Elements & Switches; Seals & Gaskets**	●	●
Up to \$150 for food and beverage spoilage in the event of a covered refrigerator or freezer breakdown	●	●

GENERATOR / ELECTRICAL ASSEMBLIES

(Factory installed assembly with separate fuel system; maximum aggregate claim amount of \$4,000 over the Plan Term, including taxes). Internally lubricated moving parts including:

Pistons; Piston Rings & Pins	●	●
Crankshaft & Main Bearings	●	●
Connecting Rods & Rod Bearings; Valve Springs	●	●
Guides & Seats; Oil Pump; Camshaft	●	●
Timing Chain Gears and/or Belt Tensioners	●	●
Rocker Arms; Engine Block	●	●

Schedule of Coverage - Motorized Recreational Vehicle Protection

GENERATOR / ELECTRICAL ASSEMBLIES (CONT.)



Cylinder Head & Cylinder Barrels only if damaged due to the failure of a covered part and component					●	●
Starter; Electrical Generator; Switches; Hour Meter					●	●
Gauges; Voltage Regulator; PC Board					●	●
Factory Installed 12/110/220V Electrical System					●	●
Wiring; Outlets & Power Converter/Inverter					●	●
Monitor Panel; Solar Panels; & Transfer Switch					●	●

AWNINGS

The Left & Right Manual Spring Assembly; Roller Drive on Slide Topper; Manual Dead Bolt Locks; Power Awnings Motors					●	●
---	--	--	--	--	---	---

STATIONARY LEVELING JACK SYSTEM

(Factory installed or approved)

Motors; Pump/Jack Assembly; Lines					●	●
Cylinders; Electric Switch; Wiring Harness					●	●
Air Bags; Fittings; Braided Hydraulic Lines					●	●

POWER STEP (Factory installed or approved)

Motor; Gear Box; Control Module; Cables (only if broken); wiring; actuator switches					●	●
---	--	--	--	--	---	---

SLIDE OUT(S)

Motors; Pump Assembly; Braided Lines					●	●
Fittings; Cylinders; Worm Gear					●	●
Electric Switch; Wiring Harness					●	●
Raised Roof Extension System					●	●
Slide Cables (only if broken); Pulleys; Hydraulic Side Arm					●	●

ENGINE RETARDER

Main Throttle Control Switch; Solenoid						●
Linkage Butterfly Plate						●


EMISSIONS

Cam Shaft Sensor; Canister Purge Solenoid						●
Knock Sensor; Crank Angle Sensor; EGR Solenoid						●
EGR Valve; Idle Speed Control Motor						●
Mass Air Flow Sensor; Manifold Pressure Sensor						●
O2 (Oxygen) Sensor; PCM Coolant Temp Sensor						●
Serviceable Throttle Position Sensor (TPS)						●
Canister Vent Solenoid						●
Emissions parts and components are covered for the Plan Term to maximum of five years or 140,000 kilometres (whichever occurs first), from the In-Service Date and zero kilometres. Emission parts and components listed are covered only when they relate to emissions performance Breakdown.						●

DELUXE COMPONENTS (Factory installed or approved)

Rear Monitor System or Backup Monitor System						●
Freezer includes only the Thermostat, Thermocouple, Burner Assembly, Igniter, Cooling Unit, Fittings; Connections & PC Board						●
Microwave Convection; E-plex Wiring & Modules; Induction Cook Tops; Dishwasher includes only the Drive Motor, Pulley, Heating Element, & Water Pump						●
Washer/Dryer includes only the Drive Motor, Transmission, Pulley, Heating Element, Igniter, Main Controls, Blower, & Water Pump						●
Trash Compactor includes only the Compactor Motor, Compacting Ram(s), & Relays						●
Central Vacuum Cleaner System includes only the Electric Motor, Armature, & Relays						●

DELUXE COMPONENTS (CONT.)



Fireplace includes only the Blower Motor, Flicker Motor, Controls and Switches, Heating Elements, PC Boards, Modules, & Circuit Breakers						●
Manual Electronic Control Pad (sleep number beds only)						●
External BBQ includes only the Burner, Igniter, & Control Valves						●
Tilt/Telescopic Steering Assembly; Spot Light System						●
Carbon Monoxide/Smoke Detector Alarm Sensors						●
Garbage Disposal; Electronic/Remote Entrance						●
Thermometer; Compass; Central Locking System						●
Supplemental Restraint System (SRS); Self-Adjuster Springs						●
Hood & Hood Hinges; Hood Latches & Springs						●
Power Seat System; Seat Tracks						●
Interior/Exterior Light Fixtures (excluding Bulbs)						●
Electrical Outlets; Glove Box Door Hinges & Lock						●
Shift Lever; Television Lift Motors; Thermostat; Propane Leak Detector; Ice Maker						●
Power Seat System; Seat Tracks; Hood & Door Hinges; Hood Latches & Springs; OEM Remote Control System for Slide Out/Appliances; Serviceable Blind Motor						●

AUDIO/VISUAL PACKAGE (Factory installed or approved)

Television (maximum television replacement value of \$1,000 per repair)						●
Speakers; CD/DVD Player; Radio; Antenna Motors						●
Rear Stereo System; GPS and Navigation System (maximum aggregate claim amount limited to \$3,000)						●

*Drive Coverage - available on new units only

**Seals and Gaskets for the parts and components listed in the part and component group



Experienced Based Refund (EBR) / Guaranteed Price Rebate (GPR)

(Available on qualifying plans)

If the plan you select includes EBR/GPR, you can apply for a refund as soon as the contract/policy expires by time. Refunds are based on the amount you originally paid for the contract/policy, up to a maximum of \$2,000, less the deductible.

- Original contract/policy holder must still be registered owner.
- No mechanical or other benefit claims made during the entire term.
- Refund must be requested and claim received within the allotted time frame.

Some restrictions apply - see contract/policy for details.



Additional Benefits Included in **All Levels of Coverage**

No Deductible will apply to the following benefits:



TECHNICAL ASSISTANCE ON TOLL FREE 24 HR LINE

1-877-975-5338 (included for first 12 months of term available for full term)



RENTAL

In the event of a covered breakdown, we will pay or reimburse you for receipted expenses up to \$250 per claim to rent a replacement vehicle or reimburse you for actual taxi or public transportation expenses.*



TRIP INTERRUPTION

In the event that a breakdown occurs more than 160 km from residence and results in a repair facility keeping your unit overnight, we will pay for receipted motel and restaurant expenses up to \$600 per claim.*

*Some restrictions apply - see contract/policy for complete details.

Emergency Road Service

Available toll free on 24 hour line 1-877-342-2492 or by reimbursement.



TOWING

Up to \$500 towing assistance if your unit experiences a breakdown causing it to be immobile while traveling.



BATTERY SERVICE

Attempting to start the unit.**



DELIVERY SERVICE

Delivering emergency supplies of gasoline, oil, or coolant (you are responsible for paying for such emergency supplies upon delivery).**



EXTRICATION SERVICE

Attempting to extricate the unit if it is stuck and can be reached safely.**



LOCKSMITH SERVICE

Unlocking the unit if the keys are locked inside or replacing the keys if broken.**

**Up to \$200 per claim.



Mechanical Breakdown Contracts
Administrator / Obligor
First Canadian Repair Protection
320 Sioux Road
Sherwood Park, AB T8A 3X6



Mechanical Breakdown Policies
Administrator / Underwriter
Millennium Insurance Corporation
320 Sioux Road
Sherwood Park, AB T8A 3X6

Toll-Free PH: 1.800.381.2580
Local PH: 1.780.467.9575
Toll-Free FX: 1.800.304.4031
Local FX: 1.780.467.9812

*NOTICE: The contents provided in this brochure are only a summary of certain terms and conditions of the contract/policy. Please refer to the actual contract/policy for complete details of coverage and exclusions. Not all contracts/policies are available in all provinces, and specific provisions may vary based upon individual provincial requirements.